



# MR10

## SERVICE MANUAL

### ■ TOP COVER



### ■ SIDE PANEL



### ■ CONTENTS


SPECIFICATIONS .....	1
CAUTION IN DISASSEMBLYING .....	1
RHYTHM PATTERN .....	1

BLOCK DIAGRAM .....	3
PRINTED CIRCUIT BOARD (Parts side) .....	3
SCHEMATIC DIAGRAM .....	4







# SCHEMATIC DIAGRAM






SW Assembly



Parallel-Serial Converter II



Read Only Memory VA (ROM VA)




\* All voltages measured with a 10MΩ/V DC electric meter, under no-signal condition.  
\* This schematic diagram is subject to change without notice.


Yamaha MR 10  
Scanned by Loscha



## BLOCK DIAGRAM



## PRINTED CIRCUIT BOARD (Parts side)



### SEMICONDUCTOR LEAD CONFIGURATIONS

